

#### IN THE UNITED STATES PATENT AND TRADEMARK OFFICE

In re Patent Application of: KHADAVI	) )		
Serial No. 09/684,536	)	Examiner:	A. Wahba
Filing Date: October 6, 2000	)		
Confirmation No. 1536	)	Art Unit:	2661
For: SYSTEM AND METHOD FOR BROADBAND ANALYSIS OF	, ) )		

DECLARATION UNDER 37 CFR §1.131

JUL 0 1 2004

Technology Center 2600

Mail Stop Amendment Commissioner for Patents P. O. Box 1450 Alexandria, VA 22313-1450

TELEPHONE LOCAL LOOP

Sir:

- I, KAMRAN R. KHADAVI, do hereby declare and state:
- 1. I am the sole inventor of claims 1-43 as originally filed in the above-identified patent application.
- 2. Prior to September 3, 1999, the effective date of U.S. Patent No. 6,266,395 to Liu et al., while employed at Harris Corporation in Camarillo, California, I conceived the invention of a bandwidth analysis tool that is operative as a system and method for broadband analysis of a telephone local loop. I worked diligently from conception in developing the software and hardware on which it is to be run, including pseudo-code, up to the time of filing the instant patent

In re Patent Application of:
KHADAVI

Serial No. 09/684,536

Filing Date: October 6, 2000

application. My invention includes a system and method for analyzing a telephone local loop. In one aspect of the invention, the system and method determines the physical loop faults within the local loop, qualifies the local loop for a particular digital subscriber line (DSL) technology, quantifies the local loop by calculating the signal-to-noise ratio, and calculates the data rates of the local loop for a particular DSL technology.

- asymmetric DSL and the system could model the local loop by modeling resistance, inductance, capacitance, and conductance (RLCG) primary constants and the line parameters for various segments of the local loop. These line parameters can be modeled as based on frequency and RLCG primary constants.

  Also, a particular DSL technology could be selected from a configurable list of DSL technologies.
- 4. This conception is reflected in Exhibit 1, which is taken from my laboratory notebook. These entries reflect that I had defined basic measurements of the bandwidth analysis tool of the present invention on pages 98 and 99. Pages 101 and 102 define Shannon's law in terms of items that are known or measured relative to the present invention and

In re Patent Application of: KHADAVI

Serial No. 09/684,536

Filing Date: October 6, 2000

provides a list of measurements that may be obtained with the bandwidth analysis tool of the present invention.

- 5. Page 102 is a memorandum setting forth details regarding the requirements of the present invention showing the bandwidth analysis tool module requirements for relevant data. That memorandum sets forth details regarding what can be used to analyze a line for DSL capability and a failure threshold with individual paths/margin/fail indications.
- 6. Exhibit 2 is a brief memorandum detailing the intended physical platform for the bandwidth analysis tool of the present invention and the types of product output, measurement input, and requirements of a cable fill tolerance prediction tool. I note that the software would later be implemented for the model.
- 7. Exhibits 1 and 2 are dated before September 3, 1999, and show a basic conception of the system and method of the present invention for determining physical loop fault, qualifying and quantifying the local loop, calculating the data rates, and modeling of the local loop.
- 8. After September 3, 1999, I worked diligently on my bandwidth analysis tool with line modeling as shown in Exhibit 3, taken from pages 119-123 of my laboratory notebook.

  I also prepared preliminary pseudo-code as reflected in

In re Patent Application of:

KHADAVI

Serial No. 09/684,536


Filing Date: October 6, 2000

Exhibit 4 and later drafted an invention disclosure. Exhibits 3, 4, and 5 reflect work accomplished after September 3, 1999. I worked diligently with the patent attorney to draft and complete a patent application covering my invention. This patent application was filed on October 6, 2000.

- 9. The dates are deleted on the sheets for Exhibits 1-5, with Exhibits 1 and 2 reflecting conception and work on my invention prior to September 3, 1999.
- herein of my own knowledge are true and that all statements made on information and belief are believed to be true; and further that these statements were made with the knowledge that willful false statements and the like so made are punishable by fine or imprisonment, or both, under Section 1001 of Title 18 of the United States Code and that such willful false statements may jeopardize the validity of the application or any patent issued thereon.


fune 12, 200 C

PAMPAN D PHADAUT



The power at any single frequency less than 15 kHz as measured by tent equipment with a handwidth of 30 Hz shall not exceed the greater of 0 dBms or 10 dB halow the measured idle channel noise. 10.4.2 Impulse noise puring initialization and operation of the ADIL system, with my holding tom applied to the circuit under text, there shall be no more than fifteen courts in fifteen minutes at a threshold of 47 denoco at either the PSTN or the POTS interface. During intraligation and operation of the ADEL system, with a 13 dBmo holding tone at 1004 Hz applied to the circuit under text, there chall be no more than yellew counts in fifteen mindes at a threshold of 65 dBmco at either the PITN or the TOTE wherefore W51 T1.413 nd dfent Phu, WG : 20, There impulse noise requirements shall be met with each of the test loops ground in 10.21 with the ADSI system forced do re-initially e once per minute during the test internal. ANS, Standard T1.413 Come two Hardel & Cottoman April wete 52 Estimation of the able length. Length = (NVP &C)/A & fres) Length/m = (NV8 +300)/(4 + fray/MHZ) Length/w = 300/ (A + tom/MHZ x SART (E)) NVP - nominel velout y propagations (0,5 to 0,9 c)

E dielectric Constant y the calle insulting



#### WTP Bandwidth Analysis Module Requirements

The current WTP design provides raw data results of various "wide band" copper cable anomalies. The purpose of the analysis module is to analyze these raw results both individually and collectively to determine the acceptance of the line to carry the desired xDSL service.

What Harris product actually performs the analysis is TBD, although it is likely CTS6000 in the near future. Eventually, WTP or its successor may perform this function as an optional module.

There are seven relevant data that can be used to analyze a line for DSL capability:

- Noise: A single result of noise averaged over a specified frequency range. Result is in dBm, dBm, or dBm/HZ.
- Noise versus frequency: An array of measured noise averaged measured over a smaller frequency range (i.e. 4khz) duplicated up to 255 times over a wider frequency range. Results are in dBm, dBm, or dBm/HZ.
  - Impulse noise: A measure of number of counts of detected impulses over a specified threshold over a specified period of time. Result is in number of counts.
  - Bridge tap location and length: Results are returned in length from RTU to "bridge" (connection of undesired pair), and the length of that "tap". Lengths are reported in feet or meters.
  - Loss: The RTU may interact with a third party hand-held equipment located at the customer premises to perform wide band loss measurements. The user may also have the ability to manually input the loop loss into the system. Result is in dBm.
  - Length: Loop length in feet or meters.
  - RTU VER code: The majority of the time, the loop will not be wide-band tested if the RTU voice-band test failed, but some marginal loops may still allow xDSL service. Refer to the RTU manual for VER code information.
- Facility information: If a DLC is detected, that loop may or may not support all kinds of xDSL service.

Each of these will require a pass, marginal, and failure threshold that may or may not be different for each xDSL service available. In addition, the all of the noise measurements may have to be adjusted to estimate the worst case noise present (see attached document).

Now, the bigger problem. The results above may provide 8 individual pass/marginal/fail indications, but our customer wants to know only one result, "can this loop carry the desired xDSL service, and at what data rate?". A method must be developed to combine length with any number and any combination of the remaining 7 results to produce a pass, marginal, or failure result of the line under test and an estimated data rate. (Note: one possible solution is to try to normalize each of the results to a common unit {i.e. dBm} that can be added, and the total added error must be less than a defined mask".

References: For ADSL-DMT, see T1.413, issue 2, For ISDN, T1.601; There are many references available on the T1.org web-site amongst others.

Actual Noise Ango = neasural Noise Ango + [Cable-loss/ft \* Calul II - Chh-lugth]
[OBm]

# Bandwidth Analysis Tool Mini-MRD

#### Background

Digital Subscriber Line (DSL) provisioning and rollout is hampered by the transmission characteristics of the copper outside plant. One of the biggest challenges to a service provider is the estimation of the transmission technology type and potentially achievable bit rate of that technology on a specific telephone pair. The Bandwidth Analysis Tool is a software product that integrates RTU Multimeter testing, Wideband Test Pack (WTP) loop performance measurements, and cable records information to make a recommendation of the "best" service that a pair can provide.

#### **Desired Product Output**

- 1. The Bandwidth Analysis Tool output is a recommendation of the "best" technology and bit rate to use on a line. The meaning of "best" takes two forms. The first form is the fastest technology and the achievable bit rate of that technology. The second form is a more stable or reliable service technology that provides "good" data rates. Therefore, the output is two text items indicating the fastest technology and bit rate, and the more stable/reliable technology and bit rate.
- 2. The second use of the Bandwidth Analysis Tool is to start with a desired DSL technology and use the RTU test results to confirm that this technology will work on the selected copper pair.

#### **Intended Platform**

The Bandwidth Analysis Tool is intended to run on the CTS-6000 platform. Both the CUI and new GUI interfaces shall be supported.

#### Measurement Input

The following Remote Test Unit measurement data form the input to the Bandwidth Analysis Tool. (This list is important to achieve alignment between customer facing marketing collateral for the product and the actual technical solution behind the scenes.)

- RTU loop test results data including length.
- RTU loaded loop test.
- WTP noise margin spectrum data.
- WTP circuit loss data (two-ended loss test or some new single-ended technology)
- WTP wideband circuit balance.

- RTU loop resistance.
- WTP impulse noise reading??? (Takes too long; may not give real benefit).

#### **Records or User Input**

The following user input data is required to assist with the analysis.

- Cable pair gauge and makeup.
- Presence of Downstream DLCs.
- Presence of alarm circuits in the same binder group.

#### Phase 2 Feature: Cable Fill Tolerance Prediction Tool


Jonathan Chien raised the point that a service provider would want to be able to predict what would happen to existing DSL customers in a cable or binder group as new services were added. This would give them a tool to proactively perform bandwidth management and noise margin management of the outside plant without upsetting existing DLS services.


This feature is very powerful, but requires a full cable records dataload into the CTS-6000 database (or a way to externally access it) along with the storage of all of the new WTP data. The new product technology that would be required to support this feature are listed below:


- Full cable records with binder group data and DSL line identification.
- Storage of noise floor and circuit impedance data for each DSL line.
- Creation of a mathematical model to determine the incremental impairment of a DLS loop as a new disturber of a specific technology type is added to the binder group.
- Creation of software to implement this model over the large CTS-6000 data set and provide meaningful and usable output.
- This feature can be tied in with the Bandwidth Analysis Tool to warn the user of the potential upset of neighboring DSL lines and make a recommendation of a technology that causes the least spectrum impact to a cable binder group.


This is truly a Next Level Solution concept!


70.00











# **Bandwidth Analysis Tool (BAT) Engine Design Document** (Preliminary Pseudo-code)

Prepared by:

Kamran

Khadavi

**Creation Date:** 

2000

Revision: 1.4

**Revision Date:** 

2000

# **Revision History**


Rev	Date	By	Description
1.0		Kamran Khadavi	Initial Draft
1.1		Kamran Khadavi	Added Model Loop and its functions
1.2	 i	Kamran Khadavi	Added Calculate Insertion Loss function and more
etails to	o Calculate A	BCD matrices function	
1.3		Kamran Khadavi	Added Signal to Noise Ratio and Calculate Data Rate
ınction	ıs		
1.4		Kamran Khadavi	Added BAT System and BAT Engine simplified
lowcha	rte		

flowcharts


1.	Overview 3			
1.2	2 BAT System Simplified Flowchart	3		
1.3	3 BAT Engine Simplified Flowchart	4		
2.	Pseudo-code BAT Engine	5		
3.	Pseudo-code to Determine Phys	sical Loop Faul	ts	6
4.	Pseudo-code to Analyze XDSL	7		
5.	Pseudo-code to Analyze Symmo	etric DSL	8	
6.	Pseudo-code to Analyze Asym	metric DSL	9	
7.	Pseudo-code to Qualify Loop	10		
8.	Pseudo-code to Quantify Loop	12		
9.	Psuedo-code to Model Loop	13		
10.	Pseudo-code to Calculate Loop	's ABCD Matri	ces	14
11.	Psudo-code to Model the Prima	ary Constants R	LCG	15
12.	Pseudo-code to Calculate Inser	tion Loss	16	
13.	Pseudo-code to Calculate Line	Paramters	17	
14.	Pseudo-code to Setup Signal to	Noise Ratio	18	
15.	Pseudo-code to Calculate Data	Rate 19		

### 1. Overview

# 1.2 BAT System Simplified Flowchart



# 1.3 BAT Engine Simplified Flowchart



# 2. Pseudo-code BAT Engine

```
Inputs:
    Test Results from WTP, RTU and Plant data
    Threshold Data (technology and sub_tech dependent), from a setup
table
    Downstream and Upstream transmit Signal Data (technology
dependent),
    Technology ID
Outputs:
    Pass/Fail status
    Reason for failure and/or status information
    Downstream data rate
    Upstream data rate
{
        Determine Physical Loop Faults
        Analyze loop for xDSL
    // end of BAT Engine pseudo-code
}
```

# 3. Pseudo-code to Determine Physical Loop Faults

```
Inputs:
    Test Results from WTP, RTU and Plant data
    Technology dependent Threshold Data (technology dependent)
     Technology ID
Outputs:
    Pass/Fail status
    Reason of failure
{
    if Load Coil Information is Available
             if Load Coil Present
                  set PassFail = FAIL;
                  set status Load Coil Present;
             else
              set PassFail = PASS;
    else
             set Reason for failure, Load Coil Information Not
Available;
}
```

### 4. Pseudo-code to Analyze XDSL

```
Inputs:
    Test Results from WTP, RTU and Plant data,
    Threshold Data (technology dependent),
    Downstream and Upstream transmit Signal Data (technology
dependent),
    Technology ID
Outputs:
    Pass/Fail status
    Reason of failure
    Downstream data rate
    Upstream data rate
   switch (Technology ID)
         // symmetric technoloigies
         case BAT_HDSL:
         case BAT_HDSL_1160:
         case BAT_HDSL_584:
         case BAT_HDSL_392:
         case BAT_SDSL:
         case BAT_SDSL_144:
         case BAT_SDSL_400:
         case BAT_SDSL_784:
         case BAT_SDSL_1040:
         case BAT_IDSL:
              Analyze Symmetric DSL;
         break;
      // Asymmetric technologies
      case BAT ADSL:
      case BAT RADSL:
      case BAT HDSL2:
          Analyze Asymmetric DSL;
      // VDSL is processed separately
      case BAT VDSL:
          AnalyzeVDSL;
          break;
      default:
          set PassFail = FAIL
     set Reason for failure, technology not supported
    } // end switch (Technology ID)
   // end Analyze XDSL
```

# 5. Pseudo-code to Analyze Symmetric DSL

```
Inputs:
    Test Results from WTP, RTU and Plant data
    Threshold Data (technology dependent)
    Downstream and upstream transmit Signal Data (technology dependent)
    Technology ID
Outputs:
    Pass/Fail status
    Reason of failure
    Downstream data rate
    Upstream data rate
    Qualify Loop
    if Loop Qualified
         switch (Technology ID)
                  case BAT_HDSL:
                  case BAT HDSL 1160:
                  case BAT_HDSL_584:
                   case BAT_HDSL_392:
                       Quantify HDSL
                  break;
              case SDSL:
                   case SDSL_144:
                   case SDSL_400:
                   case SDSL_784:
case SDSL_1040:
                   case SDSL_1568:
                        QuantifySDSL
                   break;
                   case BAT IDSL:
                        Quantify IDSL
                   break;
          } // end switch (Technology ID)
} // end Analyze Symmetric DSL
```

# 6. Pseudo-code to Analyze Asymmetric DSL

```
Inputs:
    Test Results from WTP, RTU and Plant data,
    Threshold Data (technology dependent),
    Signal Data (technology dependent),
    Technology ID

Outputs:
    Pass/Fail status
    Reason for failure
    Downstream data rate
    Upstream data rate

{
    Qualify Loop
    Quantify Loop
} // end Analyze Asymmetric DSL
```

#### 7. Pseudo-code to Qualify Loop

```
Inputs:
    Test Results from WTP, RTU and Plant data,
    Threshold data (technology dependent),
    Technology ID
Outputs:
    Pass/Fail status
    Reason of failure
{
    if Load coil information available
             if Load coil present
                  set Pass/Fail status = FAIL;
                  Set Reason of failure status, Load Coil Present =
TRUE;
             else
             LcoilPresent Status = FALSE;
    else
              set status Load Coil Information Not Available =
NOT AVAIALBALE;
    if Impulse Noise test results available
              if Impulse Noise Count less than threshold count
                  set status ImpulseCountHigh = PASS
              else
                  set status PassFail = FAIL
                  set status ImpulseCountHigh = FAIL
              }
     else
              set status WimpulseTestNotAvailable = NOT_AVAILABLE
       Number of Ringers less than threshold
              set Reason of failure status RingerFault = PASS
     else
              set status PassFail = FAIL
              set Reason of failure status RingerFault = FAIL
} // end Qualify Loop
```

# 8. Pseudo-code to Quantify Loop

```
Inputs:
    Test Results from WTP, RTU and Plant data,
    Threshold data (technology dependent),
     Signal Data (technology dependent),
     Technology ID
Outputs:
    Pass/Fail status
    Reason of failure
    Downstream data rate
    Upstream data rate
                  (note: currently identical for both directions)
    setup power spectral density of transmit data for downstream
    setup downstream signal-to-noise-ratio array
    calculate downstream data rate
    setup power spectral density of transmit data for upstream tranfers
    setup upstream signal-to-noise-ratio array
    calculate upstream data rate
} // end Quantify Loop
```

# 9. Psuedo-code to Model Loop

```
Inputs:
        Number of Channels,
        Start Frequency,
        Delta Frequency,
        Test Results,
        Technology ID,
Outputs:
        Loop Data
{
        set source and load impedances
        If Wire Gauge Information available
                Set Wire Gauge
        Else
                Set Wire Gauge to default wire gauge
        If Bridged Tap Information is not available
                Set number of taps to zero
        Else
        {
                Calculate Loop's ABCD matrices
        }
        Calculate Insertion Loss of the loop
} // end Model Loop
10.
```

# 11. Pseudo-code to Calculate Loop's ABCD Matrices

```
Inputs:
       Number of Channels
       Start Frequency
       Delta Frequency
       Length of the segment
       Wire Gauge
       Bridged Tap Flag
       Loop Data
Output:
       Loop Data
{
       initialize loop [ABCD] to unity
       do for all segments of the loop
              Do for the frequency range
                     Model the RLCG Constants
                     Model Line Paramters
                     If it is Bridged Tap section
                     {
                            A = 1
                            B = 0
                            C = Ctanh (Gamma)
                            D = Ctanh(Gamma)/Z0;
                     }
                     else
                     {
                            A = D = C \cosh (Gamma)
                            B = Csinh(Gamma) * Z0;
                            C = Csinh(Gamma) / Z0;
                     }
                     Multiply by the accumulated [ABCD] from previous segments
              } // end do for the frequency range
       } end do for all segments of the loop
} // end Calculate loop's ABCD matrices
```

# 12. Psudo-code to Model the Primary Constants RLCG

```
Inputs:
    Frequency in kHz
    Wire Gauge

Outputs:
    Primary Constants, RLCG

{
    if Wire Gauge Information Available
        set cable model parameters based on the wire gauge
    else
        set cable model parameters using average of AWG_24 and AWG_26

    Calculate Primary Constants, RLCG

}
```

#### 13. Pseudo-code to Calculate Insertion Loss

# 14. Pseudo-code to Calculate Line Paramters

```
Inputs:
    Frequency
    Primary Constants (RLCG)

Outputs:
    Line Parameters

{
    Z = R + j*2*PI*f*L;
    Y = G + j 2PI*Frequency*C;
    Gamma = Csqrt(Z*Y);
    Z0 = CSqrt(Z/Y);
} // end Calculate Line Paramters
```

15.

# 16. Pseudo-code to Setup Signal to Noise Ratio

```
Inputs:
        Number of channels
         Start Frequency
        Delta Frequency
         PSD data
         Wmargin data
         Loop data
         Downstream flag
Outputs:
         Signal to noise ratio for all channels
Do for all channels
                  convert transmit signal PSD from dBm/Hz to dB
                  calculate signal level at receiver end
                  convert noise to dB
                  signal to noise [dB] = signal [dB] - noise [dB]
}
}
         // end for all channels
         // end Setup Signal to Noise Rațio
17.
```

#### 18. Pseudo-code to Calculate Data Rate

```
Inputs:
        Bat Results
        Number of Channels
        Start Frequency
        Delta Frequency
        Signal to noise data
        Technology ID
        Downstream flag
Outputs:
        Downstream/upstream data rate
{
        Switch (Technology ID)
                case BAT ADSL:
                if (Downstream)
                         for channels 33 through 255 (excluding channel 64)
                                 signal_to_noise [dB] = signal_to_noise - snr_margin - snr_gap
                                 if (signal_to_nois > 0)
                                 {
                                          Delta Capacity = log2(1 + pow(10.0,0.1*signal_to_noise
        [dB]))
                                          If (Delta Capacity > MAX BIT)
                                                  Delta Capacity = MAX BIT
                                          If (Delta Capacity < MIN_BIT)
                                                  Delta Capacity = MIN BIT
                                          Downstream Data Rate = Downstream Data Rate +
                                                                   Delta Capapcity * data_frame_rate
                                 }
                }
                else
                 {
                         for channels 6 through 31 (excluding channel 16)
                                 signal_to_noise [dB] = signal_to_noise - snr_margin - snr_gap
                                 if (signal_to_noise > 0)
                                 {
                                          Delta Capacity = log2(1 + pow(10.0, 0.1*signal to noise)
        [dB]))
                                          If (Delta Capacity > MAX BIT)
                                                  Delta Capacity = MAX BIT
                                          If (Delta Capacity < MIN_BIT)
                                                  Delta Capacity = MIN_BIT
                                          Upstream Data Rate = Upstream Data Rate +
                                                                   Delta Capapcity * data_frame_rate
                                 }
                }
                break;
                case HDSL2:
                Not implemented yet
```

```
break;

case BAT_VDSL:

break;

default:

for all channels
{

signal_to_noise ratio = signal_to_noise ratio - snr_margin - snr_gap

if (signal_to_noise_ratio > 0)
{

Delta Capacity = log2(1 + pow(10, 0.1 * signal_to_noise ratio))

Total Capacity = Total Capacity + Delta Capacity * data_frame_rate
}

}

// Calculate data rate
```

PAGE	4	ô <b>₽</b>	
		•	

## HARRIS CORPORATION

#### PROPRIETARY INFORMATION

# INVENTION DISCLOSURE

(Accompanying Extension to Record of Invention)

Division:	NSD
Folder #:	DR-224

Invention Title:	Bandwidth Analysis Tool (BAT)
1	

#### FIELD OF THE INVENTION

The present invention is directed to communication systems in general, and is particularly concerned with qualifying and quantifying loops for DSL (Digital Subscriber Line) technologies and/or recommending the best technology, for a given application, for the loop under test.

#### BACKGROUND OF THE INVENTION

The inability to pre-qualify copper loops accurately has been a significant obstacle for the local exchange carriers (LECS). Pre-qualification is critical because all flavors of Digital Subscriber Line (DSL) deployment is dependent on the design and quality of the outside plant (OSP) and DSL technologies are blocked by the presence of load coils. Pre-qualification is the testing of loops to determine if the loop is capable of supporting DSL transmission prior to attempting to provide service – a hot topic in the industry. The ability to qualify a loop without having to dispatch technicians to either the central office (CO) or the customer's premises will result in significant cost savings for the LEC. The significant number of DSL services projected by the industry implies a strong need for an automated testing capability to handle the growing line volume.

The loop qualification goal is to predict a loop's capability to support Digital Subscriber Line (DSL) services across the entire range of frequencies over which the technology operates.

The current Wideband Test Pack (WTP) design provides raw data results of various "wide band" copper cable anomalies. The purpose of the Bandwidth Analysis Tool (BAT) is to analyze these raw results both individually and collectively to determine the capability or acceptance level of the line to carry the desired DSL service.

#### SUMMARY OF THE INVENTION

The Bandwidth Analysis Tool (BAT) analyzes the raw data results from the Wideband Test Pack (WTP), and plant record data, to qualify and quantify the loop under test for a particular DSL technology. Alternatively, the Bandwidth Analysis Tool (BAT) analyzes the WTP data and plant record data to recommend the best technology for a given application. The analysis consists of loop qualification and quantification based on the WTP raw data results, plant record data, loop topology and insertion loss of the loop. The insertion loss of the loop is calculated by modeling the loop, with or without bridged taps, taking into account the cable type and gauge and loop length and topology. Signal to noise ratio of the received signal is calculated using the technology dependent transmit signal power spectral density templates and noise versus frequency data results from the Wideband Test Pack (WTP). The downstream and upstream data rates are calculated for the loop under test.

E-1006r2b\_bat5.DOC

#### HARRIS CORPORATION

#### DR-224 INVENTION DISCLOSURE (cont'd)

PROPRIETARY INFORMATION

The algorithm for loop qualification and quantification consists of two principle functions:

- 1. Determination of physical loop faults
- 2. Analyzing for DSL technology

Determination of physical icop faults is performed by testing for shorts, opens, load coils, etc.

Analyzing for DSL technology is performed by analyzing for symmetric DSL or asymmetric DSL as appropriate. Loop qualification is done by testing for presence or absence of load coils, impulse noise counts, and ringers counts and comparing the counts with thresholds specified by the given technologies.


Loop quantification is performed for DSL technologies by modeling the loop under test, calculating signal to noise ratio and calculating data rates. In the case of symmetric DSL technologies, downstream and upstream data rates are equal. In the case of asymmetric DSL technologies, downstream and upstream data rates are calculated based on downstream and upstream transmit signal power spectral densities (PSD), insertion loss and noise versus frequency measurements.


Loop quantification for VDSL is performed as a special case, due to the restrictions of the bandwidth of WTP. In the case of VDSL, loop quantification is performed based on the loop topology rather than using signal to noise ratios.

In the case the mode is set to "recommend best technology", the technology is set to a DSL technology from a configurable list of technologies and the analysis is performed for each technology in the list until the loop qualifies or continues analysis of the loop for the next technology in the list or the list is exhausted, in which case the program returns "Falled" status. In the case the loop qualifies for a DSL technology, the status is set to "Pass" and the recommended technology is set to the current technology for which the loop is being analyzed for, and calculated data rate(s) are returned.

The following flowcharts depict a simplified high-level flow of the algorithms:

For further information, refer to Bandwidth Analysis Tool (BAT) pseudo-code.





HARRIS CORPORATION

DR-224 INVENTION DISCLOSURE (cont'd) PROPRIETARY INFORMATION

KNOWN PRIOR ART (IF ANY)

None known at this time.